Mazda Repairs

Front end

- 1. Loosen lugs. Jack up front end on jackstands, make sure high. Secure rear wheels
- 2. Remove driver side wheel (21mm), place under car
- 3. Spray everything with PBblaster. Do it again.
- 4. Get bottle of vinegar for rusty hardware not being replaced

1) CV Axle:

- 14. 32 mm socket
- Flathead screwdriver
- Breaker bar
- Torque wrench
- Pickle fork (autozone)
- Seal puller
- Hammer
- Rubber mallet
- Prybar
- Drip pan
- Penetrating oil
- Cv axle
- Spindle nut 32mm
- CV axle c clip
- Tie rod cotter pin
- Stabilizer links
- 1. Unplug ABS wheel speed sensor
- 2. Unindent axle nut on hub with flathead and hammer
- Wedge big prybar onto lugs, unscrew axle nut (32mm socket) USE BREAKER BAR
- 4. Spray splines & ball joint nut again
- 5. **ONLY IF NEED** Remove tie rod (14mm), may need hammer.
- 6. Remove stabilizer bar link & ABS bracket (14mm & allen)
- 7. Go to lower control arm step 1 /
- Reverse old axle nut on bolt, hammer cv joint inwards and pull hub out. Be careful of brakeline, might be good to disconnect
- 9. Place drip pan. Insert fork onto tranny side cv, hammer until pop out. Can also use prybar to pop out.
- Pull seal with seal-puller if need.
 Replace by hammering with large socket.
- 11. Line up and insert outer end into hub. Hand tighten axle nut.

2) Front lower control arms:

- 14, 17, 19 mm
- Flathead screwdriver
- Breaker bar
- Torque wrench
- Pickle fork or balljoint remover (autozone)
- Hammer
- Prybar
- Wirebrush
- Penetrating oil
- Loctite
- Jack for engine swing
- Balljoint pinch bolt/nut
- Lower control arm with balljoint
- 1. Remove ball joint bolt (14mm). Use wrench on opposite to keep nut still.
- 2. Remove front (19mm) and rear (2x17mm) control arm mounting bolts as much as possible.
- 3. Turn wheel to left. Hammer flathead into balljoint pinch groove.
- 4. Either use pickle fork or hammer control arm downwards until balljoint is out. Turn wheel straight.
- 5. **SKIP FOR DRIVER SIDE.** Remove rear engine mount bolt (17mm). Pry or jack engine forward, remove pass. side front mount bolt for control arm.
- 6. Wiggle out whole control arm.
- 7. Wire brush clean mounting surfaces
- 8. Compare new and old parts to ensure correct fit.
- 9. \Go to CV axle step 8.
- Insert new control arm. Loctite & hand tighten bolts & nuts. Rear bolts (17mm) require centering, use prybar.

- 12. Grease spline with fluid, insert tranny side into tranny. Aim & hammer until clipped in. Might take a lot of force. Pull to ensure clipped
- 13. Go to lower control arm step 10. ₹
- 14. Fully torque axle nut to 200 ft/lb. Indent rim into groove.
- 15. Refill tranny fluid
- 16. Lower jack to suspend hub.
- 17. Go to **front struts** ↓

- 11. Pry/jack engine forward again for front mount bolt (19mm), loctite & insert.
- 12. Line up & insert new ball joint end into hub.
- 13. Lower & reattach rear engine mount bolt, loctite! (17mm, 80 ft/lb)
- Jack balljoint into hub. Hammer down if necessary until it lines up properly. Loctite & insert pinch bolt.
- 15. Jack to ride height & torque bolts. Rears (77 ft/lb), front (110 ft/lb), balljoint bolt (43 ft/lb)
- 16. Reinstall tie rod end (14mm) & pin, torque (35 ft/lb).
- 17. √Go to CV axle step 14.

3) Front struts

- 14. 17mm
- Flathead screwdriver
- Allen wrench
- Breaker bar
- Torque wrench
- Needlenose
- Brakleen
- Loctite
- Paper towels
- Hammer
- Rubber mallet
- Wire brush
- Penetrating oil
- Strut assembly & hardware
- 1. Spray knuckle and all stuff with pb blaster, turn wheel left
- 2. Pry out brakeline clip & remove brakeline to side
- 3. Remove knuckle/strut pinch bolt (17mm). BREAKER BAR
- 4. Spray knuckle again, hammer knuckle down until strut is out
- 5. Remove 3 strut tower bolts & remove strut
- Wire brush and clean inside of knuckle. Brakleen & paper towel to finish.
- 7. Insert new strut top first.

4) Front brakes

- 17, 21mm
- 7mm Allen
- Extension
- Torque wrench
- Wire brush
- Paper towels
- Pliers
- Flathead
- Mallet
- Brakleen
- Lithium grease
- Silicone brake grease
- New brake components
- 1. Remove wheels, turn hub outwards
- 2. Use pliers to remove spring clip
- 3. 7mm allen, remove slider pins on back. Pry off plastic
- Remove caliper & outer brake pad, be careful of hose. Hang on coil to get out of way.
- 5. Unbolt caliper bracket, 2x17mm. Remove and set aside for cleaning.
- 6. Remove rotor. May need hammer the rotor itself.
- 7. Use brakleen on hub, wire brush. Clean bracket. **Lithium** grease hub
- 8. Brakleen new rotor surfaces, wipe off film. Mount on hub.

- 8. Loctite new top bolts, hand tighten strut
- 9. Align strut bottom with knuckle, watch back guide.
- 10. Jack knuckle upwards onto strut until bolt hole matches.
- 11. Clean pinch bolt, loctite, and reinsert. Torque to 54 ft/lb (17mm).
- 12. Reinstall sway bar end link & ABS bracket(14mm + allen). Torque 40 ft/lb.
- 13. Reinstall brake clip and tap in. ABS plug too.
- 14. Lower jack & tighten upper bolts (25 ft/lb).
- 15. Reattach wheels (87 ft/lb). Done!

- 9. Remount bracket, clean bolts, loctite, torque to 75ft/lb.
- Remove inner pad from caliper, clean caliper & pins. Silicone into pin holes
- 11. Use tool to depress piston
- 12. **Silicone** grease & mount outer pad into bracket. Brakleen pad surface
- 13. Clean & silicone new inner pad & mount. Grease piston seal as well.
- 14. Reinstall caliper, insert slider pins & torque 22ft/lb. Rubber caps.
- 15. Install new spring clips, hammer lightly, Brakleen rotor again in case
- 16. Depress brake couple times, recheck seating, done!

Rear end

- 5. Loosen wheel lugs. Jack up rear end on jackstands, make sure high. Secure front wheels
- 6. Remove wheels (21mm), place under car
- 7. Spray everything with PBblaster. Do it again.

1) Rear coils

- 14, 17mm
- Allen
- Torque wrench
- Breaker bar
- Wirebrush
- Penetrating oil
- Loctite
- Coilsprings
- Grease
- Rubber hose
- Sway bar end links
- 1. Unplug ABS clip
- Remove both sway bar end links (14mm & allen), swing sway bar down
- 3. Jack up knuckle/lower control arm, then undo connecting bolt (17mm).
- 4. Slowly lower jack until spring is free. Spring will force arm out of knuckle.
- 5. Repeat 3-4 to other side.
- 6. Go to rear control arm ↗

2) Rear control arms

- 17mm
- Prybar
- Breaker bar
- Torque wrench
- Ratchet extension
- Rubber mallet
- Wirebrush
- Penetrating oil
- Loctite
- Upper arms & lateral links
- 1. Remove upper arm inner bolt (17mm). Need long extension
- Remove outer bolt (17mm), hold away brake assembly. Pry out upper arm
- 3. Remove lateral link lower & upper bolts (17mm). Pry out.
- 4. Compare parts. Match upper arm length to old, use bolt to line up
- 5. Wirebrush clean mounting surfaces
- 6. Loctite bolts
- 7. Replace lateral link, torque 85 ft/lb.

- 7. Replace sway bar bushings if can/need.
- 8. Compare coils & orient
- Clean spring seat & grease. Cut tube of rubber for bottom of new coil & grease. Clean lower mounting area.
- 10. Replace spring, jack up arms until bolt lined up.
- 11. Loctite bolt & torque 70 ft/lb.
- 12. Reattach new sway bar links (14mm & allen). Torque 35 ft/lb.
- 13. Go to rear shocks ↓

 Replace upper arm. Pound in with mallet if need. Reattach brake assembly. Torque 85 ft/lb. Go to rear ← coils step 7.

3) Rear shocks

- 12, 13, 17mm
- Torque wrench
- Breaker bar
- Ratchet extension
- Penetrating oil
- Rubber mallet
- Vise grips
- Flathead screwdriver
- Wirebrush
- Shock
- ½ tsp almond extract
- 1 cup chopped pecans

1 Lower knuckle to hand free

- 1. Lower knuckle to hang free.
- 2. Spray topbolts & bottom bolt.
- 3. Remove 2 topbolts (13mm). Pull down shock.
- 4. Spray bottom bolt again, remove (17mm). Compress shock & jimmy out
- 5. Remove upper mount nut (12mm). Use impact or vise.
- 6. Place mount & boot on new shock. Tighten nut (13mm). Vise to hold stud in place.
- 7. Wirebrush clean mounting surfaces.
- 8. Reinstall shock into bottom mount. Bolt & torque (74 ft/lb)
- 9. Jack up knuckle to get upper mount into position over studs.
- 10. Secure upper mount nuts (13mm, 21 ft/lb).
- 11. Lower jack, reattach ABS plug, reattach wheels (87ft/lb). Done!

GET AN ALIGNMENT!!!