

Instrukcja sSUMMER POLE- INSTRUKCJA MONTAŻU

Uwagi dotyczące bezpieczeństwa

1. Przed pierwszym użyciem należy zapoznać się dokładnie z instrukcją i zachować ją na przyszłość.
2. Należy uwzględnić wszystkie ostrzeżenia i środki ostrożności łącznie z etapami montażu. Ze sprzętu można korzystać jedynie zgodnie z jej przeznaczeniem.
3. Mając na względzie własne bezpieczeństwo, produkt należy zamontować i użytkować zgodnie z niniejszą instrukcją. Należy poinformować wszelkich innych użytkowników o zasadach bezpiecznego użytkowania.
4. Sprzęt może montować i użytkować jedynie osoba dorosła. Dzieci nie powinny korzystać ze sprzętu bez nadzoru osoby dorosłej.
5. Przyrząd należy sprawdzić pod kątem uszkodzeń lub zużycia przed każdym użytkowaniem.
6. Maksymalna waga obciążenia: 80 kg
7. Summer pole można używać w każdym nie kamiennym podłożu (wyjątek- rurka składana obrotowo-statyczna nieprzeznaczona do wody). Przy wkręceniu w ziemię lub bardziej kamienne podłoże należy się liczyć z tym, że kamienie mogą zetrzeć farbę, ale świder jest ocynkowany. Ocynk jeżeli zostanie uszkodzony mechanicznie i zostanie usunięty z powierzchni może powodować korozję świdra (nieznaczna korozja w dolnej części świdra nie wpływa na jego funkcjonalność).

NAJWAŻNIEJSZE INFORMACJE DO RURKI SUMMER POLE

1. rura Summer Pole obrotowo-statyczna występuje tylko w wersji składanej
2. wersji obrotowo-statycznej nie możesz zamontować w wodzie ze względu na tożyska
3. montaż Summer Pole statyczno-obrotowej wymaga solidnego podłoża dla świdra. Montaż w piasku nie zda egzaminu. Przy ruchach bocznych świdra, rurka będzie po chwili niestabilna.
4. ze względu na tożyska, rurka i wszystkie jej części, powinny być oczyszczone i osuszone po każdym użytku
5. Świder wkręcony w wodzie nie możesz zostawić na kilka tygodni/ miesięcy. Należy go wyciągać po zakończeniu używania i oczyścić oraz osuszyć

MONTAŻ RURKI SKŁADANEJ LUB JEDNOCZĘŚCIOWEJ STATYCZNEJ

W zestawie znajduje się: rurka składana lub jednoczęściowa, świder, klucz, łącznik (do rurki składanej), biała tuleja

1. **Włóż białą tulejkę do świdra, dopasowując dziury w tulejce do dziur w trzpieniu świdra. Dziura przewiercona na wylot w białej tulejce powinna być dopasowana do otworu w trzpieniu świdra zaznaczonego białą kropką (śruba dociskowa, najdłuższa). Przykręć tuleję dwoma krótszymi śrubkami. Na tym etapie nie wkręcaj śruby dociskowej!. Zaczynij wkręcać świder rękami na tyle aby mógł się sam utrzymać w podłożu**

2. Włóż klucz do świdra

3. Dolną część rury umieść w kluczu, na odcinku 30 cm (ta część rury wchodzi później do świdra, więc może być porysowana). Na tym etapie montażu NIE należy dokręcać śruby dociskowej w świdrze (zaznaczona białą kropką). Dokręcamy świder do momentu zetknięcia się talerza z podłożem. Jeżeli poczujesz znaczny opór (nierównomierny) zmień miejsce wkręcania świdra, gdyż możesz zgąć klucz do wkręcania.

4. Wyjmij klucz i włóż dolną część rury, w taki sposób, aby wycięcia w niej dopasowały się do świdra.

5. Następnie dokręcamy śrubę dociskową oznaczoną białą kropką z optymalną siłą, tak, aby nie powstało wgniecenie w rurze. Użycie zbyt dużej siły przy dokręcaniu może spowodować wgniecenie w rurze, przez co wyjęcie rury ze świdra może być utrudnione.

6. Wykręcamy śrubki z łącznika i wkładamy łącznik w dolną część rury. Wkręcamy dwie dolne śruby palcami nie do końca, tylko na tyle, aby łącznik nie opadał w dół. Wkładamy drugą część rury i wkręcamy palcami kolejne dwie śrubki. Kluczem imbusowym zaczynamy dokręcać śrubki od góry do dołu, czyli w taki sposób aby jak najmocniej dokręcać po kolei każdą śrubkę zaczynając od góry. Dokręcanie z góry do dołu powtarzamy 4-6 razy aż wszystkie śrubki będą wkręcone do końca. Należy pamiętać, aby za każdym razem dokręcać każdą śrubkę z równomierną siłą. (Jak dokręcać śrubki patrz zdjęcie)

Punkt 6 nie dotyczy summer pole jednoczęściowych, dotyczy tylko rury składanej.

Ważne!

Nie można od razu docisnąć np. jednej śrubki na maksa podczas kiedy druga będzie jeszcze niedokręcona. Czynność z dokręceniem powtarzamy znowu od góry do dołu dopóki łącznik nie będzie dobrze rozparty wewnątrz rury a rura będzie stabilna na łączeniach. Te śrubki należy przykręcić mocno, ale z równomierną siłą na wszystkie cztery śrubki.

JAK DOKRĘCIĆ ŚRUBKI W RURZE SKŁADANEJ.

Nie można od razu docisnąć jednej śrubki na maksa podczas, kiedy druga będzie jeszcze niedokręcona. Śrubki należy wkręcać równo, jeżeli nie możesz wkręcić śrubki sprawdź czy śrubka wkręca się prostopadle do gwinta. Na początku nie potrzebujesz dużej siły żeby wkręcić śrubę jeżeli tak się dzieje sprawdź czy śruba wkręca się równo

1. Wykręć śrubki z jointa
2. Włóż jointa
3. Dokręć śrubki D i C pozostawiając je 1 cm na wierzchu
4. Włóż górną część rurki na jointa i dokręć śrubki A i B pozostawiając je 1 cm na wierzchu
5. Po kolei dokręcaj maksymalnie śrubki D, C, B, A w podanej kolejności,
6. Po dokręceniu wszystkich śrubek niektóre mogą się poluzować, więc powtórz 4-6 razy dokręcanie w kolejności D, C, B, A, czyli od dołu do góry

Czynność z dokręceniem powtarzamy znowu od dołu do góry dopóki łącznik nie będzie dobrze rozparty wewnątrz rurki a rura będzie stabilna na łącznikach. Te śrubki należy przykręcić mocno, ale z równomierną siłą na wszystkie cztery śrubki.



DEMONTAŻ

Rura statyczna składana lub jednoczęściowa

Zaczynamy od rozkręcenia łącznika (rurki składane). Zaczynamy rozkręcać śrubki od góry do dołu. Po odkręceniu czterech śrubek dociskowych wyciągamy łącznik i ściągamy górną przedłużkę.

Jeżeli mamy rurę **jednoczęściową** zaczynamy od wyciągnięcia rurki ze świda.

Jak to zrobić? Luzujemy śrubę dociskową zaznaczoną białą kropką, pozostałe śrubki pozostawiamy, mają być wkręcone. Stajemy oboma stopami na talerzu i wyciągamy rurkę ze świda.

Następnie wkładamy klucz do którego wkładamy dolną część rurki (lub rurę do wkręcania) i wykręcamy świder.

KONSERWACJA

Świder po użyciu należy każdorazowo oczyścić z gruntu, jeżeli był wkręcany w wodę to należy go również osuszyć.

Nie zalecamy zostawiania sprzętu przez dłuższy czas w ziemi lub wodzie ponieważ może być problem z wykręceniem świda. Dłuższe pozostawienie sprzętu w ziemi może spowodować korozję. Łożysko w adapterze w rurce statyczno-obrotowej nie jest wyciągane, należy je wydmuchać i oczyścić szmatką. Powierzchnię rurki czyścimy również szmatką.

Wszystkie instrukcje w .pdf All instructions in .pdf		Instrukcja video Video instructions	
---	---	--	---

M-pole Martyna Miłek
Trembeckiego 11
35-234 Rzeszów
791-870-977, 730-113-110
sklep@m-pole.pl

TAG US! IG, FB, TikTok, YouTube @mpoleshop

SUMMER POLE- INSTALLATION INSTRUCTIONS

Safety notes

1. Before first use, read the instructions carefully and keep them for future reference.
2. Take into account all warnings and precautions including assembly steps. Use the equipment only for its intended purpose.
3. With a view to your own safety, install and use the product in accordance with these instructions. Inform any other users about the rules of safe use.
4. Only an adult may assemble and use the equipment. Children should not use the equipment without adult supervision.
5. The equipment should be checked for damage or wear before each use.
6. Maximum load weight: 80 kg
7. Summer pole can be used in any non-stony ground (exception- the folding rotary-static tube not intended for water). When screwing into the ground or more stony ground, expect that stones may rub off the paint, but the auger is galvanized. Zinc if mechanically damaged and removed from the surface can cause corrosion of the auger (slight corrosion in the lower part of the auger does not affect its functionality).

HIGHLIGHTS FOR SUMMER POLE

1. The Summer Pole spin-static is only available in a collapsible version
2. the static-spin version you can not install in water because of the bearings
3. installation of Summer Pole static-rotating requires a solid base for the auger. Mounting in sand will not pass the test. With lateral movements of the auger, the pole will be unstable after a while.
4. Because of the bearings, the pole and all its parts, should be cleaned and dried after each use
5. You can not leave the auger screwed in water for several weeks / months. It should be taken out after use and cleaned and dried

INSTALLATION OF FOLDING POLE OR ONE-PIECE STATIC POLE

The kit includes: folding or one-piece pole, auger, wrench, connector (for folding pole), white sleeve

1. Insert the white sleeve into the auger, matching the holes in the sleeve with the holes in the auger stem. The hole drilled all the way through in the white bushing should match the hole in the auger stem marked with a white dot (pressure screw, the longest one). Tighten the bushing with the two shorter screws. Do not screw in the dosic screw at this stage! Start screwing the auger with your hands enough to hold it in the ground by itself
2. Insert the wrench into the auger
3. place the lower part of the pole in the key, at a distance of 30 cm (this part of the pole later enters the auger, so it can be scratched). At this stage of assembly, do NOT tighten the pressure screw in the auger (marked with a white dot). Tighten the auger until the plate touches the ground. If you feel a significant resistance (uneven) change the screwing place of the auger, as you may bend the screwing key.
4. Remove the wrench and insert the lower part of the pole, so that the notches in it fit the auger.
5. then tighten the pressure screw marked with a white dot with optimal force, so that no indentation is formed in the pole. Using too much force when tightening may cause an indentation in the pole, making it difficult to remove the pole from the auger.
6. remove the screws from the connector and insert the connector into the lower part of the pole. We screw in the two lower screws with our fingers not all the way in, just enough so that the coupler does not fall down. We insert the other part of the pole and screw in another two screws with our fingers. Using an allen wrench, we start tightening the screws from top to bottom, that is, in such a way as to tighten each screw as tightly as possible one by one starting from the top. Tightening from top to bottom is repeated 4-6 times until all screws are screwed in completely. Be sure to tighten each screw with even force each time. (See photo for how to tighten the screws).

Point 6 does not apply to summer pole one-piece, it only applies to the folding pole

Important!


You can not immediately tighten, for example, one screw to the maximum while the other will still be unscrewed. The operation with tightening is repeated again from top to bottom until the connector is well spread inside the pole and the pole is stable at the joints. These screws should be tightened firmly, but with even force on all four screws.

HOW TO TIGHTEN THE SCREWS IN A FOLDING POLE.

You cannot immediately tighten one screw to the maximum while the other will still be unscrewed. Screw the screws in evenly, if you cannot screw a screw in check that the screw screws in perpendicularly to the threaded hole. Initially you do not need a lot of force to screw the screw in if this happens check that the screw screws in evenly

1. Remove the screw from the joint
2. Insert the joint
3. Tighten screws D and C leaving them 1 cm on top
4. Put the top of the pole on the joint and tighten screws A and B leaving them 1 cm on top
5. One by one, tighten screws D, C, B, A to the maximum in the order given,
6. Once you have tightened all the screws, some may come loose, so repeat 4-6 times the tightening in the order D, C, B, A, i.e. from bottom to top.

Repeat the tightening process from bottom to top until the coupling is well spread inside the pole and the pole is stable at the joints. Tighten these screws firmly but evenly on all four screws.



DISASSEMBLY

Folded or one-piece Summer Pole static

We start by unscrewing the connector (folding poles). We start unscrewing the screws from top to bottom. After unscrewing the four pressure screws, we pull out the connector and remove the upper extension.

If you have a one-piece pole, we start by pulling the pole out of the auger.

How to do it? Loosen the pressure screw marked with a white dot, leave the remaining screws and screw them in. We stand with both feet on the plate and pull the pole out of the auger.

Then we insert the key into which we insert the lower part of the pole (or the pole for screwing in) and unscrew the drill.

MAINTENANCE

After each use, the auger should be cleaned from the ground, and if it was screwed into water, it should also be dried.

We do not recommend leaving the equipment in the ground or water for a long time because it may be difficult to unscrew the auger. Leaving the equipment in the ground for a longer period of time may cause corrosion. The bearing in the adapter in the static-rotating pole is not pulled out, it must be blown out and cleaned with a cloth. We also clean the pole surface with a cloth.

All instructions in .pdf		Video instructions	
--------------------------	---	--------------------	---

M-Pole Martyna Miłek
Trembeckiego 11
35-234 Rzeszow, Poland
+48 791-870-977, +48 730-113-110
sklep@m-pole.pl

TAG US! IG, FB, TikTok, YouTube @mpoleshop