StroboClip HDC™ Settings Screen ⚙

Your StroboClip HDC has two screens of operation in which parameters can be adjusted. For more advanced use, the Settings Screen allows for detailed adjustment as well as system information.

Click the **Menu** button five times or until the **Gear Icon** flashes. Click the Plus (+) or Minus (-) Value button to enter the Settings Screen.

The adjustable settings within the Settings Screen and their default values are:

Parameter	Value Options	Default Value
Global Color	10 Default Colors	Orange
Global Accidentals	Sharp / Flat / Both	Sharp
Configuration	dEF / USR	dEF
Auto-Order Presets	On / Off	On
Factory Reset	Click the Plus + Value button to start factory reset	
Firmware Version	View Only	
Hardware Version	View Only	
Exit ⚙	Click Plus + or Minus − Value to exit to Tune Screen	

After changing the desired settings, press the **Menu** button to confirm the changes and navigate to the **Exit Setting**. Use the Plus (+) or Minus (-)Value button to exit the Settings Screen, or allow the setting to time out and return to the Tune Screen. For an in-depth look at the Settings Screen parameters and their uses, visit:
www.petersontuners.com/products/stroboClipHDC/settings

Reminder: Your StroboClip HDC has two screens of operation in which parameters can be adjusted. The Settings Screen allows for more detailed adjustment as well as system information. All adjustments of settings after this message require the user to first access the settings screen.

From the Tune Screen, click the **Menu** button five times or until the **Gear Icon** flashes. Then, click the Plus (+) or Minus (-) Value button to enter the Settings Screen.

Global Color



Upon entering the Settings Screen, Global Color is the first adjustable parameter. The word **Global Color** will scroll in the lower right of the display. Use the Plus (+) or Minus (-) Value button to select your Global Color.

Note: Global Color affects all display colors on the StroboClip HDC except for those already set via the tune screen. If a display color has been selected in the tune screen, it will save to that Sweetener Preset and will override the Global Color Settings.

Global Accidentals



To adjust the Global Accidentals setting, first enter the Settings Screen. Click the **Menu** button until **Global Accidentals** scrolls in the lower-right corner of the display. Use the Plus (+) or Minus (-) Value button to select from one of the three Global Accidental settings. The three available Global Accidentals settings are:

# SHP	Sharps: F# C# G# D# A#
♭ FLT	Flats: Gb Db Ab Eb Bb
♯♭ BTH	Both: A combination of both sharps and flats in common enharmonic equivalents F# C# Ab Eb Bb

Configuration



To view and change the Active Configuration, first enter the Settings Screen. Click the **Menu** button until a large **C** appears in the center of the screen and Configuration scrolls in the lower-right corner of the display. Use the Plus (+) or Minus (-) Value button to choose between **dEF** (default) or the three letter name of any custom configuration, commonly **USR** (user).

Auto Order Presets 

To view and change the Auto Order Presets setting, first enter the Settings Screen. Click the **Menu** button until a large **A** appears in the center of the screen and Auto-Order scrolls in the lower-right corner. Use the Plus (+) or Minus (-) Value button to choose either **On** or **Off**. Auto Order Presets reorders your most recently used Sweetener Presets to the top of the list. This allows you to access your most recently used Presets with just a few button pushes.

Factory Reset 

To perform a Factory Reset, first enter the Settings Screen. Click the **Menu** button until the words **Factory Reset** scroll in the lower-right of the display. Click the Plus (+) Value button to initiate a Factory Reset. A countdown timer will begin after the reset is initiated. Pressing any button before the countdown completes will cancel the Factory Reset.

Factory Reset will erase <u>all</u> user settings. Any color changes, drop/capo settings, concert A reference, or changes made within the Settings Screen will be reset to their factory defaults.

Firmware and Hardware Version 

To view the current Firmware or Hardware Version, first enter the Settings Screen. Click the **Menu** button until **Firmware** or **Hardware** scrolls in the lower-right of the display. The version number will immediately scroll after the words Firmware or Hardware.

Exit

To exit the Settings Screen, Click the **Menu** button until the word **EXIT** scrolls in the lower-right of the display and the **gear icon** flashes. Click the Plus (+) or Minus (-) Value button to exit the Settings Screen and return to the Tune Screen.