FAST DRAW
INSTRUCTIONS

ONE, TWO, THREE OR FOUR PLAYERS - - 3 BALLS PER PLAYER

INSERT COIN OR PRESS CREDIT BUTTON TO RESET MACHINE.
REPEAT FOR ADDITIONAL PLAYERS
POINTS ARE SCORED AS INDICATED.
COMPLETING A-B-C SEQUENCE DOUBLES BONUS VALUE. BONUS SCORES DOUBLE ON LAST BALL OR TRIPLE IF A-B-C SEQUENCE IS COMPLETED. COMPLETING EITHER GROUP OF DROP TARGETS AND A-B-C SEQUENCE LIGHTS CORRESPONDING HOLE ALTERNATLEY FOR SPECIAL. COMPLETING BOTH GROUPS OF DROP TARGETS RESETS CENTER DROP TARGETS FOR 5000 POINTS.
A-B-C SEQUENCE AND DROP TARGETS RESET AFTER EACH BALL.
CENTER BUMPER SCORES 10 OR 1000 POINTS WHEN LIT.
BONUS IS SCORED AFTER COMPLETION OF BALL IN PLAY.
A TILT DOES NOT DISQUALIFY A PLAYER.

379 B-15946-3

