

**SIM卡**

鑑於香港實名制監管，SIM卡需要先用手機開通登記，並記錄SIM卡號碼。詳細實名登記方法請參閱SIM卡包裝，手機能上網代表已開通。

## 首次使用設定

在幾分鐘內，設備將會搜索到4G信號(閃綠燈)和GPS信號(閃藍燈)，並開始正常運作，在正常狀態下指示燈將在5分鐘後熄滅。

## APP使用

<https://play.google.com/store/apps/details?id=com.yw.yuntrack&hl=en&gl=US>

第一行:選擇「[www.qpsci.com](http://www.qpsci.com)」

第三行:密碼, 預設密碼為123456(可更改)

第四行：記住登錄訊息

### APP主畫面



正中:設備設定

歷史軌跡: 查看設備過去位置路徑

**電子圍欄：**設立圍欄，當設備經過圍欄後手機會發出提醒

更多

命令下發:GPS有額外功能設定, 但不建議改動以免影響設備運作。GPS需喚醒在線時才能接受命令。離線時可使用SMS發出命令, 但電訊商會收取費用。

設備報表:統計數據

設備訊息:記錄GPS設備、車型等資料

使用者亦可登入網站[www.gpscj.com](http://www.gpscj.com) (車牌號/ID號) 查看GPS位置。

#### 機身指示燈說明

| 綠色指示燈:4G訊號 |       | 藍色指示燈:GPS訊號 |        | 紅色指示燈:電源 |      |
|------------|-------|-------------|--------|----------|------|
| 情況         | 狀態    | 情況          | 狀態     | 情況       | 狀態   |
| 閃動         | 通訊正常  | 閃動          | GPS正常  | 紅燈長亮     | 正在充電 |
| 常亮         | 無通訊信號 | 常亮          | 無GPS信號 |          |      |
| 綠燈不亮       | 關機或休眠 | 藍燈不亮        | 關機或休眠  |          |      |

#### 注意事項

GPS設備主要為實時追蹤用途, 而非哨兵模式般有極高靈敏度去偵測任何震動的用途。

請保持設備在乾燥的環境中使用。

裝置越少發出/接收信號, 數據及電量消耗較少。裝置在移動中定時上傳位置數據。

GPS以低耗電原理運作, 需要移動才會喚醒顯示運動, 裝置不動會顯示靜止, 靜止一段時間會進入休眠, 顯示為離線。

GPS管理平台由香港[鐵騎部品]進行管理, 我們並不會亦無法追蹤特定顧客與設備的位置, 除非由顧客提供裝置資料。

首次啟動設備時, 接受衛星訊號需時較久, 強烈建議把GPS放置在戶外。

GPS裝置基本不需要改動任何設定, 已可安心使用追蹤。

請保存紀錄好IMEI、密碼和SIM卡號碼。

GPS裝置可以邊充電邊使用

#### 進階指令(下方表格)

注意, 使用SMS發出命令, 但電訊商會收取費用。

| Function        | set command format | Reply                                                                                                                              | Cancel | Example | Remark |
|-----------------|--------------------|------------------------------------------------------------------------------------------------------------------------------------|--------|---------|--------|
| parameter query | param,1            | Software version, ID, IP, port, domain name, APN                                                                                   |        |         |        |
|                 | param,2            | Administrator number, SOS number, displacement distance, overspeed speed, automatic defense time, disarm time, alarm time interval |        |         |        |

|                                        |                                   |                                                                                                                                                                |               |                                     |                                                                                                                                                                       |
|----------------------------------------|-----------------------------------|----------------------------------------------------------------------------------------------------------------------------------------------------------------|---------------|-------------------------------------|-----------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| device status                          | status                            | Battery: 6 GPRS:<br>Normal/Abnormal GSM:<br>Strong/Good/Fair/Poor<br>GPS: A/V ACC: On/Off Gas<br>Power: On/Off External<br>Power Supply:<br>Normal/Interrupted |               |                                     |                                                                                                                                                                       |
| latitude and longitude link            | where                             |                                                                                                                                                                |               |                                     | reply google link                                                                                                                                                     |
| IMEI query                             | imei123456                        |                                                                                                                                                                |               |                                     | Reply IMEI number                                                                                                                                                     |
| master number                          | admin123456,number                | admin ok                                                                                                                                                       | noadmin123456 | admin123456,186*****                |                                                                                                                                                                       |
| Restore Factory                        | begin123456                       | begin ok                                                                                                                                                       |               |                                     |                                                                                                                                                                       |
| reboot                                 | rst                               |                                                                                                                                                                |               |                                     | The device has been dormant, and the SMS call will wake up and work for 5 minutes                                                                                     |
| APN                                    | apn,apn content,apnuser,apnpasswd | apn ok                                                                                                                                                         | apn           | apn,cmnet,user, paswd               | Just enter the APN when there is no username and password                                                                                                             |
| IP&Port&Domain Name                    | adminip123456,ip:port             | adminip ok                                                                                                                                                     |               | adminip123456, 113.98.254.178: 7700 |                                                                                                                                                                       |
|                                        |                                   |                                                                                                                                                                |               | adminip123456, d.gpscj.com:7700     |                                                                                                                                                                       |
| Time zone                              | timezone123456,A                  | timezone A ok                                                                                                                                                  |               | timezone123456 ,-4                  | After setting the time zone, the alarm SMS time becomes the corresponding time zone time, the default is 0 time zone                                                  |
| Blind zone supplementary report switch | blindrep123456,A                  | blindrep a ok                                                                                                                                                  |               | blindrep123456, 1                   | A=1 on A=0 off Default on                                                                                                                                             |
| Working mode (battery model)           | wkmd,m,t                          | wkmd m t ok                                                                                                                                                    |               |                                     | m=1 positioning data upload to judge vibration, t time range 1-12000 unit second<br>m=2 Timing upload t time range, 1-24, unit hour without t parameter, always sleep |
| start alarm                            | autorep123456,AB                  | autorep ab ok                                                                                                                                                  |               |                                     | AB=33 ON<br>AB=00 OFF<br>Default alarm mode platform and SMS                                                                                                          |
| arm                                    | 111                               | SF OK                                                                                                                                                          |               |                                     | Vibration alarm on                                                                                                                                                    |
| disarm                                 | 000                               | CF OK                                                                                                                                                          |               |                                     | Vibration alarm off                                                                                                                                                   |
| Displacement alarm                     | move,<distances(m)>,[mode]        | move ok                                                                                                                                                        | nomove        | move,500,4                          | A: Displacement distance 100-3000 B: Alarm mode: 1. Platform and SMS; 2. Platform and phone; 3.                                                                       |

|                 |                                 |          |         |            |                                                                                                                                                                        |
|-----------------|---------------------------------|----------|---------|------------|------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
|                 |                                 |          |         |            | Platform and SMS and phone;<br>4. Platform default 4                                                                                                                   |
| Overspeed alarm | speed,<over speed value>,[mode] | speed ok | nospeed | speed,80,4 | A: Speed B:<br>Alarm mode: 1. Platform and SMS; 2. Platform and phone; 3. Platform and SMS and phone; 4. Platform Default 4                                            |
| Vibration alarm | vib,<level>,[mode]              | vib ok   |         | vib,2,4    | A: Sensitivity 1-9, 1 is the most sensitive, default 2 B: Alarm mode: 1, platform and SMS; 2, platform and phone; 3, platform and SMS and phone; 4, platform default 4 |