

With the hood open it is pretty simple and straightforward. If you are unable to open your hood. Going through the grille or from underneath

Locate the cable horn on the passenger side and loosen the set screw.

Remove the driver's side kick panel to expose the hood cable lever. Pull old cable out. Remove cable retention clip.

Cut the tip of the bellow to fit the cable. The bellow is located in the rain tray by the driver's side. The small round grommet will be there as well.

Remove cable from cable shield. Route new cable shield.

Remove the grill and remove the steel latch rods. Sand and clean any rust and make sure everything is smooth and greased properly failure to do this will result in cable failures.

Remove hood pins and clean, remove rust and grease and reinstall. Using the Bentley manual to adjust properly. Failure to do this will result in cable failure

Replace drives cable horn with the non set screw billet horn.

Install new cable clips to hold the shield in place.

Run bare cable through the clip

Best to wipe cable down with white lithium or light oil.

Install bare cable into the shield, guiding it through the first horn and center shield into the final horn with the set screw. Remove set screw and coat in anti seize. Install set screw. Remove any slack and tighten.



