

Lab SOP

To Prepare a 1L 5x TBE Buffer

Tris Base	54g
Boric Acid	27.5g
0.5M EDTA (pH8)	20mL

Add H₂O to make 1L

Pass 0.2um Filter

The working concentration is 0.5x TBE (10 times dilution with water)