

ASSIGNMENTS FOR 2/27

Advanced	5TH PERIOD		
Sarah Marshall Wyatt Seaders Ben Forkner Alexander Christian Atticus Grose Caleb Evans	Kyo Bruce Jason Choi Greydon Hazelton Brayden Howland Noah Johnson	Memphis Jones Walden Kavanaugh Haggard Nick Lahanas Tristan Massey Nico Murphy Cora Sand	Adam Shepro Kami Streicher Silva Cody Surmeier Isaac Walrod Elijah White

	WORK PRIORITIES	Assignments
1	<p>INSTALL HOUSE WRAP AROUND ENTIRE HOUSE.</p> <ul style="list-style-type: none"> • Make sheets as continuous as possible. • Mark where all the studs are as you wrap so we can hit studs when installing siding. • Wrap over openings for now. Eventually, holes will be cut but done in such a way that the wrap can wrap around and into the opening framing. • All joints should be taped. • Trim all excess as needed. Make sure your utility knife is sharp. • Trim openings (but ask Mr. K how to do this first before proceeding). 	Jason Memphis Walden
2	<p>FASCIA AND FLY RAFTERS</p> <ul style="list-style-type: none"> • Cut long boards to length. The side boards should fit between the front and the back fascia boards. • Screw the side fascia boards to the rafter tails, 3" x 3 screws or nails in each rafter. • Cut and install the front and rear fascia boards. 	Adam Eli Brayden Nico Noah Tristan
3	<p>INSTALL HARDI SIDING</p> <ul style="list-style-type: none"> • Start with the tall wall and the long sheets (so that mistakes could potentially be used on the short wall). • Use the jigs that mount to the rim joists to hold pieces in place. • Cut siding so that all edges land on framing members. • Use the 3" ring-shank nails, 6" OC on edges, 12" OC in the field. • Make sure nail heads do not penetrate below the surface of the siding. 	Greydon Cody Kyo Kami Nick Cora Isaac
4	<p>INSTALL ROOF INSULATION</p> <ul style="list-style-type: none"> • Place insulation on the roof, extending over the fascia on all sides, as indicated on the layout drawing. Use 8d nails just to hold the insulation in place temporarily until the roof plywood is installed on top of it. Make sure joints in adjacent courses do not land on the same rafter. • DO NOT STEP ON THE PINK INSULATION BY ITSELF WHEN IT IS IN PLACE ON THE ROOF – YOU WILL GO THROUGH IT! 	

5	<p>INSTALL ROOF SHEATHING</p> <ul style="list-style-type: none"> • Install plywood per the layout drawing. Make sure joints in adjacent courses do not land on the same rafter. Also, make sure there is an 1/8" gap between all edges of plywood. Use the shank of a nail to space this gap uniformly. • Use 3" screws to attach to the rafters. Install screws 6"OC on the perimeters, and 12"OC in the field. 	
6		