ATC Call Scenario

Every call starts out with pretty much the same thing, just with twitch of action:

- 1. Who you are talking to
- 2. Who are you
- 3. Where are you
- 4. What you want / Action
- 5. Weather information If it the first time your talking to that facility (Tower or Ground)

Example Scenario: SWA 241 is currently parked at Spot J. Plane is checked and ready to fly.

Pilot Requesting for Taxi

"PHX GND, SWA241, at spot J, ready to taxi, with information A"

- Ground Controller Response

"SWA 241, PHX GND, Runway 26, taxi via C C6 B B13"

Pilot Response

"Runway 26, taxi via C C6 B B13, SWA 241"

Example Scenario: SWA 241 taxiing to 25R from the northern side will use taxiway T and hold short at Taxiway D.

- Pilot Requesting for taxi

"PHX Ground, SWA241, at spot J, ready to taxi with information A"

Ground Controller

"SWA 241, PHX Ground, Runway 25R, taxi via C, T, hold short at D"

- Pilot Response

"Runway 25R, taxi via C, T, hold short at D, SWA 241"

- **Ground Controller** (Once plane is on taxiway T)

"SWA241, PHX Ground, contact South Ground 120.9"

- Pilot

"Contact S Ground 120.9, SWA241"

Example Scenario: SWA 241 taxiing to Runway 26 from the southern side will use taxiway S and hold short at Taxiway C.

- Pilot Requesting for taxi

"PHX Ground, SWA 241, at Spot Y3, ready to taxi, with information A"

- Ground Response

"SWA 241, PHX Ground, Runway 26, taxi via D S, hold short at C"

Pilot Response

"Runway 26, taxi via D S, hold short at C, SWA 241"

- Ground Controller (Once plane is on taxiway S)

"SWA241, PHX Ground, contact North Ground 118.7"

- Pilot Response

"Contact North Ground 118.7, SWA 241"

***Example Scenario: SWA 241 crossing runway 25L

- Ground contacting Local (Tower) for clearance

"Local, Ground"

Local response

"This is Local, go ahead"

- Ground response

"Cross runway 25L at taxiway H7"

- Local response

"Approved, BC (The person who approving initials)"

- Ground response

"CG (The person who response to the approving initial)

- Ground talking to SWA 241 (SWA 241 holding short 25L at H7)

"SWA 241, Ground, cross runway 25L"

- Pilot Response

"Cross runway 25L, SWA 241"

Ground contacting Local (Once aircraft had cross the runway)

"Local, Ground"

Local Response

"This is Local"

- Ground response

"Crossing Complete"

Local Acknowledge

"Crossing Complete, BC"

- Ground Response

"CG"

Example Scenario: SWA 241 had taxi and currently holding short runway 26 at B13, ready to take off

- Pilot Requesting for Takeoff

"PHX Tower, SWA 241, holding short Runway 26 at B13, ready for takeoff"

Tower Response

"SWA 241, PHX Tower, fly straight out runway 26, Clear for takeoff, *Wind 130 at 26 Gusting 30"

Pilot Response

"Fly straight out, Runway 26, clear for takeoff, SWA 241"

Tower Control Scenarios