

ASSIGNMENTS FOR 4/3

Advanced	5TH PERIOD		
Sarah Marshall Wyatt Seaders Ben Forkner Alexander Christian Atticus Grose Caleb Evans	Kyo Bruce Jason Choi Greydon Hazelton Brayden Howland Noah Johnson	Memphis Jones Walden Kavanaugh Haggard Nick Lahanas Tristan Massey Nico Murphy Cora Sand	Adam Shepro Kami Streicher Silva Cody Surmeier Isaac Walrod Elijah White

	WORK PRIORITIES	Assignments
1	<p>INSTALL HARDI SIDING – PORCH WALLS</p> <ul style="list-style-type: none"> You may need to cut HARDI to length – check. Remember that deck boards go on the porch. HARDI can go down below these as long as they extend down below porch surface. You may wish to get some pieces of plywood to set on the porch deck framing to stand on. Cut siding so that all edges land on framing members. Use the 2-3/8" ring-shank nails, 6" OC on edges, 12" OC in the field. Make sure nail heads do not penetrate below the surface of the siding. When finished with this, install door. 	Brayden Greydon Noah
2	<p>INSTALL HARDI SIDING – REAR WALL</p> <ul style="list-style-type: none"> Have at least two different people lay each piece out first. You will need to cut around the window. You will need to use the last tall-wall side piece on the left side. When carrying the cut piece, take extreme care not to break it at its narrow section. Use the jigs that mount to the rim joists to support pieces in place while installing. These will also align bottom edges. Cut siding so that all edges land on framing members. Use the 2-3/8" ring-shank nails, 6" OC on edges, 12" OC in the field. Make sure nail heads do not penetrate below the surface of the siding. 	Cora Cody Kami
3	<p>INSTALL ROOF SHEATHING, DRIP EDGE, AND PAPER</p> <ul style="list-style-type: none"> REMEMBER THAT THE LONG NARROW PIECE OF SHEATHING NEEDS TO BE TAKEN OFF AND RECUT. Install plywood per the layout drawing. Make sure joints in adjacent courses do not land on the same rafter. Also, make sure there is an 1/8" gap between all edges of plywood. Use the shank of a nail to space this gap uniformly. Use 3" screws to attach to the rafters. Install screws 6"OC on the perimeters, and 12"OC in the field. 	Elijah Adam Jason

	<ul style="list-style-type: none"> When finished with this, paper the roof after you install the drip edge on the lower edge of the roof. 	
4	INSTALL BLOCKING ON REAR WALL FOR EAVE SIDING Install pieces of 2x4 into the rafter using 3" screws to secure. The bottom of the 2x4 should be flush with the bottom of the rear wall rafter.	Tristan
5	ENCLOSE SOFFITS WITH HARDI SIDING <ul style="list-style-type: none"> Use the small nails in the framing nailer to install. Only nail where there is blocking and/or a rafter to nail to. All underside areas of roofing will need to be sheathed. Minimize waste of HARDI siding. Work in pairs on each side of the house. 	Nico Walden Kyo Memphis
6	INSTALL TRIM ON HOUSE <ul style="list-style-type: none"> Use the small nails in the framing nailer to install. 	
7	INTERIOR CAULKING <ul style="list-style-type: none"> All joints need to be caulked, as well as holes and screw heads that are below the surface of the wood. Have some paper towels handy. Use fingers to smooth – once. Don't reuse a finger unless you have washed your hands clean. It will result in uneven caulking. Remember to release trigger when not applying caulk so that the caulking does not continue to leak from the tube. 	Isaac Nick