



Foam Wedge Backrest Insert - S40

INSTALLATION GUIDE

Thank you for choosing [Cruzbike](#) and the Foam Wedge Backrest Insert for the S40. The Foam Wedge Seat Insert offers S40 owners a seat back angle adjustment option that preserves the S40's incredibly efficient seat-to-frame-to-drive connection. It allows riders to angle their bodies further forward for around town riding or to have a more upright body position when new to Cruzbike.

Parts Included

The wedge comes with four pieces of velcro. (2) adhere the wedge to the velcro on the seat, and (2) adhere the seat cushion to the wedge.

Installation

Push the soft velcro onto the upper part of the velcro on the Carbon Fiber Seat (**first image below**) and push the stiffer velcro onto the upper part of the velcro on the cushion (**second image below**).



FOAM WEDGE BACKREST INSERT - S40 INSTALLATION GUIDE

Questions? Call us 888-225-2789 or email support@cruzbike.com

Pull backing off of the velcro on the seat back and carefully push the Foam Wedge onto the seat back (**first image below**), adhering the seat's velcro to the Foam Wedge. Next, remove the backing from the velcro on the cushion and push the cushion onto the wedge (**second image below**), adhering the cushion's velcro to the Foam Wedge.



Allow the velcro adhesive to cure for 24 hours before attempting to move the wedge. Once the velcro is cured, the wedge can be moved up and down the seat for support wherever you most need it. This less-reclined position can be excellent for owners who prefer long rides without a headrest or for those who use their S40s for around-town travel as well as endurance rides.

You're all set. Enjoy!

This is a prototype product the team at Cruzbike is excited for customers to road test. If you like this as much as we do, we will continue to evolve this concept. We're grateful for feedback on this product. Please send your feedback to product@cruzbike.com.