

MR2Heaven Greddy Style Side Skirts

Installation, Removal & Assembly Tips - 10/14/2024

Very Important - Align door to side skirt gap properly with shims **before drilling any holes** to achieve proper fitment. This gap depends largely on your chassis tolerances



Secondly - Adjust this area by grinding/removing material from this edge to achieve the ideal “pop” outwards. Try to match this with your door. This will depend largely on your chassis tolerances as well and can vary quite a bit.



As always, if you have any further questions or need support, please feel free to reach out and email

Sales@MR2Heaven.com