

Soling 1M Quick Setup Guide

Dead Glass Drifter

Mast, middle hole

Mast Rake, Top **front corner** of mast to bottom of transom = 57.5"

Mast Rake, Nose of the boat to jib attachment on mast 48.5"

Jib (end of boom to center of mast when on it's side sails pulled in 2.5"

Jib outhaul 1.0"

Main (end of boom sighted to centerline of the boat) 2.5"-3"

Main outhaul 1.5"

Main Middle Batten (boat on its side sails in) 3.5" to backstay

Boomvang - none

Backstay no tension extremely loose, just enough to keep the mast up

Light-Medium Air (ripples on the water)

Mast, middle hole

Mast Rake, Top **front corner** of mast to bottom of transom = 57.5"

Jib (end of boom to center of mast when on it's side sails pulled in 2.5"

Jib outhaul 1.5"

Main (end of boom sighted to centerline of the boat) 2.5"-2.75"

Main outhaul 2"

Boomvang - none

Backstay tension really loose, just take up the slack

Medium With Just An Occasional Big Puffs

Mast, middle hole - front if lots of weather helm

Mast Rake, Top **front corner** of mast to bottom of transom = 57.25"

Jib (end of boom to center of mast when on it's side sails pulled in 2.5"

Jib outhaul 1.0"

Main (end of boom sighted to centerline of the boat) 1.75"-2.25"

Main outhaul 1"

Boomvang - a little keep the boom from being able to rise on reaches

Backstay tension, start using - put some on to control the slot of the jib

****Mast Height 51.5**

****Jib Attachment height off deck 45 3/8**

Thanks

Scott