

Comstock Armory Plan B FHC-58-9 Info

Installation:

1. Ensure the firearm is completely unloaded
2. Clean the threads of the barrel and muzzle device with acetone
3. Apply a small amount of Rocksett to the barrel
4. Torque flash hider to approximately 30 ft-lbs with a 13/16" wrench

Notes:

- Only use an appropriate 13/16" wrench to torque the flash hider.
- Allow the Rocksett to cure for 24 hours before use.
- Crush washers may cause misalignment and should not be used with suppressors.
- The 5/8 - 24 flash hider is designed for bullets up to 9mm or .355 caliber. This includes 7.62mm or .30 cal.
- Ensure the threads and taper are clean before each use.
- Always check bullet stabilization before attaching a suppressor, and always use an alignment rod to ensure the suppressor system is set up correctly.
- Acetone and isopropyl alcohol should only be used in areas with proper ventilation.
- A drop of high temp anti seize may be used on the threads/taper if the suppressor does not come off easily. Only use food safe anti seize.
- Some suppressor companies do not warranty their products when used on aftermarket mounts or muzzle devices. Comstock Armory will not be held liable for injury, death, or damage resulting from the use or misuse of this product.