



1. Find a piece of cardboard to catch excess glue.
2. Get I bar clamps.
3. Grab a couple wet paper towels.
4. Clamp the pieces without glue to check your fit. (show instructor)
5. Apply glue evenly.
6. Wipe excess glue with paper towels and return cardboard.