

OTW's 16x25 Flow Hood

Thank you for purchasing out of this world's 16x25 flow hood!
Here are some basic instructions to get you started.

Your flow hood came fully assembled and ready to use! However these are the instructions for when you are ready to replace the filters.

Inside the hood you will see the wood stoppers that keep the filter from going too far back.

The filter faces with the tabs inward, the first step is to take the carbon pre-filter and place it inside the plastic grooves on the back wall, using the top wood stopper to hold the top. Then lay the unit on its back and place the HEPA filters in one at a time. Placing the bottom in first, between the plastic stopper and the wood stopper. Then tilt the top into the frame.

To remove filters

To remove the filters, first turn the hood on its back and move the securing latches down and out of the way, then use a knife or other thin instrument to gently push between the filters in the center near the bottom. Push towards one side while gently sliding it outwards to remove one filter at a time. The securing latches will automatically slide up when the hood is set upright.

Replacements:

This unit uses A21 (115115) true HEPA filters. Available in my store and on Amazon. When purchasing from Amazon the brand I prefer is "XBGG" as they fit properly. Some other brands do not have the true sized filters, which have an exterior dimension of $16 \frac{1}{4}'' \times 12 \frac{5}{8}''$. This unit uses 2 of those filters, and one of the carbon pre filters.

Thank you for your purchase! Mush love 🍄