

# Darky's v10.0 Beta 3

## [based on JV1, Gingerbread 2.3.2]

**// WARNING //**

**THIS IS ONLY FOR EXPERIENCED FLASHERS!**

**I GIVE ABSOLUTELY NO SUPPORT - EVEN IF YOUR SGS IS (SOFT)BRICKED.**

**Download [CWM Package]**

<http://bit.ly/darky10b3>

### Installation Instructions

**Follow this Video made by** [Vincenzo Prignano](#)

**<http://www.youtube.com/watch?v=AtOyyrFt6yA>**

- Flash JV1 ([www.samfirmware.com](http://www.samfirmware.com)) with Odin / Heimdall.
- Use 512 pit, repartition ON, **auto reboot ON**.
- Once the SGS has restarted, shut it down and get into Download Mode again.
  
- Flash a *Speedmod Kernel* with Odin (it's a Froyo kernel but we need it now).
- Put the TAR file in PDA and flash - make sure auto reboot is OFF!
- Pull the battery and put it back in.
- Close Odin, disconnect your cable from your SGS.
  
- Enter Recovery Mode [VOLUME UP + HOME + POWER - only hold them for 1-2 seconds]
- You're in the green Speedmod Recovery now.
- Flash the ROM.
- I didn't test it with a factory reset here, I just flashed and it worked.
- Reboot.
- Enjoy!

### IMPORTANT STEPS / HINTS AFTER FLASHING

**RAM Hack to prevent memory leaks [lags and crashes]**

>> Download Autokiller from Market.

>> Put these values in: 10, 16, 24, 68, 76, 92 (from top to bottom)

## **Gingerbread CRT Screen-Off Animation**

>> Settings >> Display >> Animations >> ALL

- darkyy.