



VANLIFE
OUTFITTERS

Rear Door Shower/Privacy Curtain Installation Guide

Version 1 - October 2021

Tools Needed:

- 1x: tape Measure
- 1x: drill
- 1x: 5/64 drill bit
- 1x: #2 phillips bit driver or phillips screwdriver
- 1x: marker

Note: the last page of this guide has a photo of the curtain system fully installed on Promaster van with the various parts illustrated.

Installing the Rods

Step 1)

Open both rear doors and then measure 67" up from the ground on the outside edge of each door where the rod mounting bracket will be placed and mark this spot. Note: you can adjust this mounting height based on your personal preference, i.e. how high you want the curtain rod to sit.

Step 2)

Remove the rod mounting bracket from the rod by unscrewing the stainless steel shackle pictured below:



Step 3)

Hold the rod mounting bracket vertically ensuring it is straight and at the desired height of installation. Mark the holes inside the rod mounting bracket where you will be drilling and fastening it to the van with screws. Ensure that there are no wires or vehicle components in the area where you will be drilling.

**Step 4)**

Pre-drill holes with 5/64 drill bit.

Step 5)

Install the rod mounting brackets with screws provided.

Step 6)

Remove the snap clip from the rod (pictured to the right). This is the piece of hardware that the rod will snap into to secure it to the door when not in use. Reattach the rod to the mounting bracket.

Measure down from the top of the mounting bracket straight down along the door 25"-30" on both doors (your preference, it can fall anywhere within this range) and mark the location where you wish to install the snap clip. In some cases/some vans, it's best to have the rod slightly angled so that the location of the snap clip doesn't interfere with the door handle/locking mechanism.

Snap Clip



Step 7)

Pre-drill holes to mount snap clip with 5/64 drill bit. Again, ensure that there are no wires or vehicle components in the area where you will be drilling.

Step 8)

Mount snap clip with provided screws.

Using the Shower/Privacy Curtain

Step 1)

Detach both rods from the snap clips.

Step 2)

Slide the adjacent rod into the tube connector. In order to do this you will have to loosen the knob on the top of the tube connector. Once the adjacent rod is inserted, tighten the knob until the rod is firmly secured.

**Step 3)**

Attach the shower curtain to the rod using the velcro straps attached to the shower curtain. There are two very strong magnets attached to the bottom of the curtain on both sides which enables you to secure the bottoms of the curtain by attaching the magnet to the sheet metal of the van door.



Yellow circle: rod mounting bracket

Green circle: rod (left side)

Red circle: rod connector (joins the left and right sides of the rod when in use)

Pink circles: magnets in the lower portion of the curtain.