

Routers:

Turn on router

right as it turns on and you are logged in with putty press:

CTRL + Pause

(it should show the

rommon>

interface instead of our normal interface)

confreg 0x2142

reset

(Router will reset)

N

copy run start

(now you are ready with a freshly reset router)

Switches

Unplug the switch

hold the MODE on the switch and plug in the switch at the same time wait a few seconds.

flash_init

load_helper

dir flash:

for all the .text file rename them with the next command (only do this for class - in the industry you want to use the delete command for example : Delete flash:config.text)

rename flash:config.text flash:config.old

rename flash:private-config.text flash:private-config.old

rename flash:vlan.dat flash:vlan.old

boot

Also can also use instead of renaming:

delete flash: [file]