

J100 Wire Harness Update and SOP 5/29/25

Presentation Video

<https://www.loom.com/share/2d0b909318034b41b0a1dad803bd2ec6?sid=34d6e320-2b8e-488c-943a-1f30ccda0493>

EAV SOP for securing cables

<https://docs.google.com/presentation/d/1Sq98hJyHoKk9dZZdH5t2tpB2x8lwoBB7/edit?usp=sharing&ouid=112871134411290442068&rtpof=true&sd=true>

Links for conductive grease

Silver conductive grease

<https://a.co/d/6xWVgGg>

<https://a.co/d/2GpgSgg>

<https://a.co/d/iKPKo7r>

NO-OX-ID A-Special- Electrical Contact Grease- Keeps Metals Free of Rust and Corrosion- Part# 10203 <https://a.co/d/ghf9yLo>

Electrically conductive Grease

https://www.amazon.com/dp/B082SJLJQK?ref=fed_asin_title&th=1

If none of these are available then you can use **copper** anti seize lubricant, that you will likely be able to find at that auto parts or hardware store. Make sure it is **copper** anti seize as regular anti seize will not conduct electricity.

Padding

https://www.amazon.com/dp/B08L8TCSXV?ref=fed_asin_title&th=1

https://www.amazon.com/dp/B089N6RBNJ?ref=fed_asin_title&th=1

Wire Tape

https://www.amazon.com/dp/B07THRDYNV?ref=fed_asin_title

<https://a.co/d/fLpt7mW>

<https://a.co/d/61vmKxc>