

# Post Anchors

- [Instructions](#)
- Require 1.25" bit



## Hole Saw & Arbor

~~\$20.59~~ \$14.42 (30% Savings)

Size  
1-1/4" Dia. (4x4 & 4x6)

Quantity  
1

Subtotal \$14.42

Total USD \$14.42

Pay now • \$14.42

Decline this offer

## HOW IT WORKS



### DRILL

Use an off the shelf 1-1/4" dia. by 2" deep hole saw to cut a pilot cut for the tube.  
Use a 1-3/4" dia. hole saw for 6x6 and 8x8 post anchors.



### DRIVE

Use a 3 lb mini sledge to drive tube into post beyond the depth of hole saw cut.



### FASTEN

Pre-drill holes and drive lag screws into the post.

