



How to Properly Shutdown a Chromebook

If you are not signed in to your Chromebook, select Shutdown in the lower left corner of the screen.

If you are currently signed in to your Chromebook, select the Time (located in the lower right corner of the screen)



Select the Shutdown  icon or Sign out and then Shutdown.

