

Chromebook WiFi Issues

WIFI Issue	
Issue	Possible Solutions
WIFI Issue	If you run into issues when trying to connect the Chromebook to the internet via WiFi. 1. Make sure that WiFi is on. a. At the bottom right, select the time. b. Select Not Connected . Note: If you see your Wi-Fi network name and a signal strength, your Chromebook is already connected to Wi-Fi. c. Turn on Wi-Fi. d. Your Chromebook will automatically look for available networks and show them to you in a list. e. Make sure it is connected to CRSchools Password is guestpassword 2. If WiFi is still not working, contact Building Technical Support.