

When your Chromebook Screen will not turn on

- First make sure your Chromebook is charged. You will know it is charged because a white light can be seen on the side of the Chromebook.
- Hold down the Refresh button on the keyboard and the power button on the keyboard at the same time for 10 seconds.
- Then push the power button. You may have to push the power button more than once to get the Chromebook screen to come on.

