

Student Learning Card:

Tips for Caring for my C Pen


Focus: Caring for my C Pen

Tip # 1 Putting your C Pen in its Case:


Put the screen side facing in towards the yellow sticker



Watch this video



Tip #2: How to look after the Battery



- Keep in a place that is between 16 °C to 22 °C
- Keep charged to around 50%, do not let the battery go flat
- Charge the battery at least every 3 months
- Keep dry

Tip # 3 What to do if the C Pen doesn't have any Power



- Connect the pen to a charger for at least 2 hrs.
- Press Power on for at least 3 seconds
- Push the Reset button on the back of the pen
- Push and hold the Red Power button for at least 30 seconds.

Watch this Video:



Resource:

Student Activity-Caringfor my C Pen