

1	3	4	5	11
Cat / pic ref.	description	PM Part no.	OEM	£ retail
PLEG	Nut, crankshaft cush drive, plunger		67-2054	11.50
PLEG	Cush drive spring		67-2062	7.50
PLEG	Bolt, oil pipe union securing, plunger.		67-1467	2.00
PLEG	Gearbox securing bolt, plunger, normally two fitted		67-1467	2.00
PLEG	Gearbox mainshaft split washer		67-3251	4.40
PLEG	Nut, primary chain tensioner, nylok		67-1266	0.80
PLEG	Plate, clutch, plain, thick, For plunger – Surflex, 1 fitted at rear. (2.0 mm) Wassells supplied	PMN093	67-3240	7.60
PLEG	Plate, clutch, plain, thin, For plunger – Surflex, 5 fitted. (1.5 mm) Wassells supplied		67-3241	7.60
PLEG	Plate, clutch, plain, thick, For plunger – not Surflex, 1 fitted at rear. (2.4 mm) MCA supplied	PMN093M	67-3240	5.30
PLEG	Plate, clutch, plain, thin, For plunger – not Surflex, 5 fitted. (0.85 mm) MCA supplied		67-3241	7.90
PLEG	Gear lever (long type)			42.50
PLEG	Plate, clutch, friction – plunger– Surflex	PMN095	67-3242	19.50
PLEG	Spring, clutch, usually 6 fitted		67-3247	2.00
PLEG	Nut, clutch spring		67-3249	2.90
PLEG	Roller, clutch centre. Normally 18 fitted		26-0650	0.25
PLEG	Lockwasher, clutch nut / mainshaft, plunger	PMN325	67-3253	1.40
PLEG	Crankcase oil seal, behind clutch		67-1242	3.10
PLEG	Cylinder head steady bars, plunger type, pair		67-0346	15.00
PLEG	Clutch cover dish		67-3288	13.90
PLEG	Mainshaft nut, plunger		67-3257	3.30
PLEG	Return spring, gear lever, normally two fitted, priced each		67-3146	1.20
	Steering damper assembly / kit for plunger models. Knob, rod, slotted nut, friction disc, star spring, and anchor plate.		67-5021 65-5380 25-5247 27-5152 25-5241	31.00
52	Steering damper anchor plate, plunger type (flat)	PMN271	27-5152	6.20

53	Bottom plate (plunger)		25-5241	2.70
51	Stud, anchor plate, plunger		65-5327	
PLF	Crankcase and exhaust lugs stud		67-1251 27-5690	2.60
PLF	Mudguard front bracket fixing bolt		01-5069	2.50
PLF	Front mudguard stay fork end fixing bolt		15-7354	0.90
PLF	Front stand fixing bolt		02-1934	1.40
PLF	Mudguard fixing screw, chrome BZP (chrome below)		15-7161	0.70
PLF	Mudguard fixing screw, chrome		15-7161	
PLF	Rubber connector carb / air filter, plunger	PMN362	67-4589	6.20
PLF	Spring, centre stand, plunger frame	PMN275	67-4847	10.50
PLF	Nut, left hand thread, plunger footrest fixing, nearside	PMN364	67-4856	3.40
PLF	Nut, RH thread, plunger footrest fixing, offside		67-4852	2.50
PLF	Stud, footrest, A10 plunger, LH thread, nearside		67-4041	3.50
PLF	Stud, footrest, A10 plunger, RH thread, offside		67-4029	2.90
	Set of all 4 above			10.80
PLF	Spring, brake pedal return		67-7032	8.30
PLF	Gearbox (plunger) foot setscrew		67-4028 42-7516	3.30
PLF	Bracket, rear mudguard front, left		67-6766	3.50
PLF	Bracket, rear mudguard front, right		67-6767	3.50
PLF	Dual seat bracket offside / rear		67-9093	8.50
PLF	Dual seat bracket nearside / rear		67-9093	8.50
PLF	Backstay and seat stud lug nut		15-0541	3.10
PLF	Backstay and seat stud		66-4175	2.90
PLF	Washer, saddle type for battery carrier clamp bolt, plunger, see PMN204 29-4662, dynamo clamp washer	PMN363	29-4662	1.60
PLF	Battery strap (plunger) chrome	PMN272	29-4657/3	32.50
PLF	Bolt for battery carrier strap clamp (plunger)	PMN273	29-4661	6.00
PLF	Trunnion, threaded, for plunger battery clamp strap	PMN274	65-2353	5.00
PLF	Trunnion, plain, for plunger battery clamp strap and dynamo strap	PMN275	65-2352	5.00
PLF	Pin, hinge, for plunger battery carrier strap	PMN276	29-4664	2.50
PLF	Screw, plunger toolbox lid	PMN061	29-9132	14.00
PLF	Nut, toolbox screw		02-1027	1.20
PLF	Toolbox clip washer		02-6537	

PLF	Bolt, plunger column top mounting		31-0068	3.50
PLF	Bolt, plunger suspension lower / silencer mount		67-4128	6.10
PLF	Special washer / distance piece for 67-4128		67-4129	1.30
PLF	Rear suspension shrouds - FULL SET		as below	79.50
PLF	Plunger suspension, bottom shrouds, outer (painted), sold each.		89-4240	11.00
PLF	Plunger suspension, bottom shrouds, inner (chrome) sold each.		89-4241	23.00
PLF	Plunger suspension, top shrouds, outer (painted) sold each.		89-4248	15.00
PLF	Plunger suspension, top shrouds, inner (chrome) sold each.		89-4249	17.50
PLF	Plunger suspension top spring (large / heavy), UK made, bare steel, SOLD EACH		89-4247 67-4132	19.50
PLF	Plunger suspension top spring (large / heavy), imported, zinc plated, SOLD EACH		89-4247 67-4132	7.50
PLF	Plunger suspension bottom spring (small / light), UK made, bare steel, SOLD EACH		89-4259	14.50
PLF	Plunger suspension bottom spring (small / light), imported, zinc plated, SOLD EACH		89-4259	6.30
PLF	Top nuts, alloy, plunger columns, sold each		67-4166	8.00
PLF	Clamp lug bolt, chrome, sold each		03-1399/3	5.00
PLF	Clamp lug bolt, zinc, each		82-1760	4.20
PLF	Spring, chain adjuster		15-1312	1.40
PLF	Pivot pin screw, brake rod clevis		02-0510	1.50
PLF	Screw, rear chain adjuster, ea.		66-4603	7.10
PLF	Spindle, rear wheel		67-6164	49.50
PLF	Felt washer		67-6075	1.80
PLF	Bolt, silencer clip		24-7343 70-3872	2.20
PLF	Cam, 7" brake		65-5905	16.20
PLF	Steady strap, rear brake plate		67-6081	6.50
PLF	Fulcrum pin, rear brake		65-5899	4.10
PLF	Sprocket / brake drum, rear wheel, 42T UK made		67-6150	130.00
PLF	Rear hub / bearing cover		67-6128	11.20
PLF	Hub bearing sleeve nut		67-6074	8.20
PLF	Circlip / ring, Bearing retaining, rear hub, plunger.		67-6067	1.70
PLF	Pin / trunnion, swivel, rear brake rod		65-6274	1.90
PLF	Brake rod		67-7033	10.90
PLF	Spring, brake rod (as chain adjuster)		15-1312	1.00
PLF	Adjuster nut, brake rod		29-7368 90-7029	5.95

PLF	Nut, rear spindle		67-6073	4.00
PLL	Filter, oil tank, plunger and C11	PMN034	29-7962, 82-9071	18.50
PLL	Oil hose, use ¼" fuel hose, see accessories page		65-2060	
PLL	fibre washer, Oil tank drain plug – see gaskets page		02-0100	
PLL	Banjo, oil tank connection, bottom of plunger oil tank (held on by filter)	PMN307	67-8309	11.60
PLL	Oil return pipe connector, plunger oil tank	PMN308	65-8420	7.00
PLL	Oil pipe (one pipe only)		65-8465	7.00
PLL	Drain plug		02-0084	2.90
PLL	Oil tank return pipe nut, plunger oil tank	PMN309	65-8424	6.00