

How to Force a Restart/Reboot on a Chromebook

How to Force a Restart/Reboot- Only do this if you can't properly shutdown the Chromebook. Unplug the power cable and then hold down the power button until Chromebook turns off.