
64.Lift position 5

(lift raised low)

Inspect the brakes for drag, and drain the brake fluid from the brake master cylinder.



Brake Drags

Operate the parking brake lever several times and depress the brake pedal several times in order to allow the brake shoes to settle.

Apply the parking brake lever or brake pedal until the clicking sound of the rear brake auto adjuster goes away.

2 Manually turn the brake disc or brake drum to inspect for any drag.

Brake	Fluid	Changer	instal	lation
DI UNE	, iuiu	Ciluingei	1113141	

Drain brake fluid from the brake master cylinder reservoir ta

Install the brake fluid changer.
