EPASD – Guide to Using Your iPad

Your EPASD iPad is managed by the Technology Department. There is no passcode required to use the device and all apps are managed by the district. All updates will be performed automatically. Your iPad will connect automatically to the EPASD WiFi network.

**Powering on and Connecting**

1. **Powering ON your new iPad** – press and hold the top button until the Apple logo appears.


   If iPad doesn't turn on, you might need to charge the battery.

2. **Restarting your iPad** - On an iPad with a Home button: Press and hold the top button until the slider appears, then drag the slider to "OFF". Press the top button again to restart.

3. **Connect to your home WiFi/Internet** (if you are a current iPhone user this will look familiar)

   Settings –

   Look for the WiFi setting – your home WiFi will appear on the right side.

When prompted enter your home WiFi password.
That's it! You should be connected.

Logging on to Clever

1. Locate the <mark>Clever</mark> app on the iPad

2. Scan your issued barcode badge or use your EP Google log in.

IREADY access – use the **Clever app and not the iReady app on the home screen. That is needed for iReady to properly work in Clever.