

Welcome to TouchView Interactive Panel

(this doc is a work in progress)

DEMO

Here's a quick overview of a similar model.

<https://www.touchview.com/demo.html>

Note: our models do not have a PC. Teachers will use a teacher device.

[How to use your Panel by Ockers](#)

Basic Setup

- HDMI 1 is labeled "Computer" this is the connection for the Teacher Computer (thunderbolt or USB- C)
- HDMI2 is extra HDMI cable can be used for doc cam, dvd, other
- Included Accessories - a remote and 2 magnetic pens (holder on back)

Getting Started



★ [S- Write - Whiteboard App](#) - Yes it has an infinity screen!!

★ Build in Browser

★ Connection using Macbook/Chromebook

1. Connect Touch - use the USB cable

2. Connect AV - use the thunderbolt 2 (Mac) or HDMI (Chromebook)
3. Set Display to Mirror (default is extended display)

★Casting must use Eshare App

1. Download and Install EShare App on teacher device. Go to eshare.app to download.
2. Launch the EShare App on the TouchView
3. Open the Eshare App on the teacher device.
 - a. Select TV by room name
 - b. Enter passcode
 - c. Select SHARE SCREEN and select the screen you want to share
 - d. USE PAUSE to FREEZE
 - e. USE STOP to stop Sharing
 - f.

Additional info

- [Use Eshare to cast](#)
- You may be prompted to allow permissions(Microphone, Accessibility, Screen Recording). If you do not have admin access on your device and can not grant access, please contact Tech Dept. Go to Mac Settings to allow Privacy Settings for

Power down

The power button on the TV only puts the panel to sleep. It is recommended at the end of the to use the remote to completely shutdown OR long hold on button until RED.

Cleaning

If the screen is dirty, disconnect power dampened a soft cloth with water or mild cleaner (NO BLEACH) and clean using the slightly wet cloth. Do not apply force. Tips and Additional Info

[How to use remote](#)

[TouchView Interactive Panel Manual](#)

TIPS from staff

- Infinity screen in S-write App is available!
- Use “pause” on eshare to freeze screen
- Precise eraser!!
- Quick screenshot to the S-Write board

- Activate the annotation tool (from side menu)
 - Use the middle icon to select screen capture
 - Select what you want
 - Click check
 - Auto launches into the S-write Board!!
- Save content from S_Write to GDrive - use QR code function

USE remote to POWER DOWN. Button on TV just sleep.