

QuickStart For Printing With USB Flash Drive

*The USB is the little device you are plugging into the hole to the left of the screen, right above the turn on button. If it doesn't go in when you first try to push it in, flip it so it's upside down and try again. Repeat until it goes in.

*The printer only prints images that are saved as .TIFF, JPG, HP-GL/2, RTL, PDF, or Post Script.

*The file is the image you are trying to print.

1. Insert USB into the hole to the left of the screen .
2. Tap on the image of the USB.
3. You should see a list of items pop up, these are the files that are on your USB. Find your file and tap on it (tap on the name of the picture you are trying to print). You might have to scroll up and down on the screen, or click on the folders if you've saved it in one of them.
4. Once you've selected your file, click on settings at the bottom left of the screen.
5. Once there, tap on size, and then tap on Fit to. The acronyms on the screen are for the size of the poster, and those measurements will be listed on the back of this page. Select which acronym is associated with the size you want your poster to be.
6. You should now be looking at the settings menu again. If you want to print in black and white, tap on color, then tap on grayscale.
7. Change other settings as needed. (Print quality, Roll, Rotation, Printer margins)
8. Once finished, tap on setting in the bottom left of the screen and then tap on start.

*The QR code to the right will bring you to online manual for using the printer. To scan the QR code go to your camera app, and then aim your camera at the image, and then click on the yellow link that appears below the code.



ISO: International Standard

ISO A0: Width x Height (in): 33.11×46.81

ISO A1: Width x Height (in): 23.39×33.11

ISO A2: Width x Height (in): 16.54×23.39

ISO A3: Width x Height (in): 11.69×16.54

ISO A4: Width x Height (in): 8.27×11.69

ISO B0: Width x Height (in) : 40.48×57.32

ISO B1: Width x Height (in): 28.66×40.48

ISO B2: Width x Height (in) : 20.24×28.66

ISO B3: Width x Height (in): 14.33×20.24

ISO B4: Width x Height (in): 10.12×14.33

ANSI (American National Standards Institute)

ANSI A: Width x Height (in): 8.5×11.0

ANSI B: Width x Height (in): 11.0×17.0

ANSI C: Width x Height (in): 17.0×22.0

ANSI D: Width x Height (in): 22.0×34.0

ANSI E: Width x Height (in): 34.0×44.0

Arch (Architecture Paper Size)

Arch A: Width x Height (in): 9.0×12.0

Arch B: Width x Height (in): 12.0×18.0

Arch C: Width x Height (in): 18.0×24.0

Arch D: Width x Height (in): 24.0×36.0

Arch E: Width x Height (in): 36.0×48.0