

Backing up Dedicated AAC Devices



TobiiDynavox Devices

[Indy with Snap Core First](#)

[Video](#)

[I-series -with Communicator 5](#)

Grid 3 Software

Saltillo Devices

[NovaChat Devices-Directions](#)

[Video-2.15 version and later](#)

[Video -up to 2.15 version](#)

Prentke-Romich Devices

[PRC-Accent-Directions](#)

[Video](#)

PRC-Older devices-see below

Backing up a PRC Springboard Lite or Vantage:

1. Plug a USB thumb drive into the USB port
2. Go to the TOOLBOX [F9]
3. Activate TRANSFER MEMORY MENU.
4. Select Save One User Area [Note: you only need to Save Entire Device Contents if you have IR commands to save.]
5. Choose the User Area to Save
6. Name and date the file to Save and Select OK