# ITS TechDocs

# Keiper 208: Directions for Use

## Last Revised 8-18-23

#### **General Directions**

- 1. Press the **ON** button, on the push-button controls on the rack, to begin. The projector will turn on automatically.
- 2. Press the button of the Source you desire:.

HDMI USB-C Blu-ray

- 3. Control the **Volume** with the volume-control knob.
- 4. Press and hold the **OFF** button to turn off the system.

## To Display a Laptop

- 1. Press the source you desire: HDMI or USB-C.
- 2. Attach the appropriate cable to your laptop or device.

## To Playback a Blu-ray or DVD Disc

- 1. Press the Blu-ray source button.
- 2. Use the **LG Blu-ray Disc Player** remote to control the playback.
- 3. Press the Open/Close button on the remote to eject the tray. Seat your disc. Press Open/Close again.
- 4. Press the **Disc Menu** button to navigate to the Disc Menu.
- 5. Use the playback controls to play the disc.

### **Final Shutdown**

- 1. Coil up the **HDMI** and **USB-C** cables individually, so they will not be stepped upon.
- 2. Eject any Blu-ray or DVD discs. Return the **LG** remote to the rack.
- 3. Press and hold the **OFF** button to turn off the system.

For Assistance: Call the ITS Help Desk: 717-358-6789