


How to shorten your lanyard


1. Place the flathead under the clasp



2. Twist flathead and pop open clasp.



3. Cut the lanyard to length.



4. Place the newly cut lanyard into clasp and push down on the clasp.

