Autel Explorer App
Menu and Settings

Mission Settings (Bottom of Main Screen)

- Altitude (MSL)
- Relative Altitude (AGL)
- GSD (calculated)
- Speed
- Front Overlap
- Shooting Angle
- Side Overlap
- Gimbal Pitch (should be 90°)
- Finish Action (Go Home or Hover)
- Resume (Lost Action or Go Home)
- Course Angle (can change starting point, optimize for wind/sun)
- Double Grid (On/Off)

- Elevation Optimization (Toggle on/off)

- Weather (Sunny or Cloudy-image optimization)

- Coordinated Turn (Toggle on/off)



Settings: Flight Control

- Novice Mode
- Go-Home Altitude
- Speed Mode
- Speed Limit
- Altitude Limit
- Distance Limit
- Aircraft Ascent Speed
- Aircraft Descent Speed
- Compass Calibration
- IMU Calibration
- Attitude (ATTI) Mode
- Emergency Stop Propellers During Flight

- Advanced Settings

Settings: Visual Navigation

- Visual Obstacle Avoidance
- Show Radar Map
- Auxiliary Bottom Light
- Advanced Settings

Settings: Remote Control

- Remote Control Calibration
- Command Stick Mode
- Remote Control Matching
- Remote Control customizable buttons

Settings: Aircraft Battery

- Low and Critically Low Battery Warnings
- Voltages, Temperature and Remaining Capacity

- Discharge Times

Settings: Gimbal

- Gimbal Mode, Adjust Gimbal
- Gimbal Automatic Calibration
- Gimbal Pitch Limit and Gimbal Pitch EXP Sensitivity

Settings: General

- Home Point
- Units
- Show Aircraft Coordinates
- Voiceovers
- Obstacle Avoidance notification sound
- Restore “Do Not Show Again”
- Software Update
- Select Language

- Remote ID – should say “broadcasting”

- About