Connecting to Your Epson Wireless Projector (First Time)

Watch the video at Integrate2Inspire.com/HowDol

- 1. Turn on your projector.
- 2. On your laptop, click the Windows "Start" button.
- 3. Click "All Apps."
- 4. Find "Epson Projector" in the list of applications and click on it.
- 5. RIGHT-CLICK on "EasyMP Network Projection" and select "Pin to Start."
- 6. Click on "EasyMP Network Projection" to open.
- 7. Click "Advanced Connection Mode."
- 8. Check the box that says "Set the selected mode as the default mode..."
- 9. Click "**OK.**"
- 10. When asked about the firewall, click "Yes."
- 11. At "No projector found," click "OK." THIS IS NORMAL.
- 12. Click "Manual Search."
- 13. Type in your projector's **IP address.** It is projected on the wall.
- 14. Click "OK."
- 15. Click the box next to your projector in the list.
- 16. Click "Save in the Profile."
- 17. Give your profile a name and click "Add."
- 18. Click "Connect."
- 19. Click "Disconnect" when finished.
- 20. Close the "EasyMP Network Projection" software.