


SMART Board Important Settings

Click **Settings** at the bottom left corner of the SMART board:



- Save whiteboard files to Lumio so teachers can access them online. [Click here to learn more about Lumio.](#)
 - Files Library > Under WHITEBOARD STORAGE > press Default Whiteboard Location > Select My Files Saved to Lumio
- Under Files, teachers will have Google Drive as a quick access point:
 - Files Library > Allow Google Drive integration in Files Library - turn ON
- Use your finger to write on the SMART board:
 - SMART Whiteboard > Enable Write or Draw with your Finger (Finger Inking)
- Prompt the teacher before a device automatically shares to the board:
 - Screen Share > Require Permission > Turn ON
- Customize the SMART board wallpaper:
 - Wallpaper > select an image or add an image that was saved on a USB.
- Write on anything displayed on the SMART board:
 - Annotation > Enable Annotation Layers > Turn on
- Hide passwords when typing them on the board:
 - Security > Make password visible > turn off
- Create a shortcut under Favorites on the homepage so teachers can easily access the Whiteboard app.
 - (Not in Settings) Tap Files > On the Whiteboard tile, toggle on the Star in the top right corner.
- Disable the sensor so the board does not turn when someone walks by it (6000 model only - model without an eraser):
 - Press the Menu button on the back of the board or the three lines button on the front. Navigate to Setup > Proximity off