

Royal Kludge SINK87G Functions

<p>BUILT-IN ANIMATIONS</p> <p>Change Animation: Fn + ScrLk</p> <p>Change Speed: Fn + ← / →</p> <p>Change Color: Fn + PgUp</p>	<p>CUSTOM LIGHT PATTERN</p> <p>Select: Fn + 1-9</p> <p>Record Selected: Fn + PrtSc</p> <p><i>When recording, press a key until it lights the color you want</i></p>
<p>MACROS</p> <p>Record: Fn + Ctrl + Q / W / E</p> <p>Playback: Fn + Q / W / E</p>	<p>OTHER</p> <p>Change Brightness: Fn + ↑ / ↓</p> <p>Lock/Unlock Windows Key: Fn + Win</p> <p>Factory Reset: Fn + Left Ctrl + Esc</p>