

How to use your Chromebook with an External TV using HDMI

1. Plug the cable into the HDMI port on your Chromebook and verify the correct input is selected on the TV.

2. Login to your Chromebook

The default view the first time you connect to a TV via HDMI will be extended mode so if you want to display what is on your screen, you will want to put it in mirror mode.

To put your Chromebook into mirror mode, you can do the following:

- Click on the time in the bottom right corner of your screen
- Click the Settings cog
- Select Device from the left hand side
- Then Select Displays
- Toggle the little switch next to Mirror Built-in Display