

ITS TechDocs

WVAC 202 Printmaking Studio : Directions for Use

Last Revised 10-8-20


General Instructions

1. Press the green **Power On** button on the **NEC** remote control to turn on the Plasma TV. Aim the remote towards the right, bottom portion of the screen, where a blue light will appear when the TV is ON.
2. Attach an HDMI cable from your laptop to the jack found on the wall below the TV.
3. Press the **HDMI1** button, on the remote, to see a connected Laptop.
4. Control the Volume with the **VOL +/-** and **Mute** buttons on the remote.

To Display a Laptop

1. Attach your laptop, with an HDMI cable, to the jack on the wall below the TV.
2. Press the **HDMI1** button on the NEC Plasma TV remote. Your laptop image should appear on the TV.

Shutdown

1. Neatly coil up all cables so they will not be stepped upon.
2. Press the red **Standby**  button on the **NEC** remote control to turn off the Plasma TV. A red light will appear on the bottom right of the screen.
3. Place the remote control where the next user can find it.

For Assistance: Call the ITS Help Desk: 717-358-6789