

Casa 1 - Operation Instructions of Electronics

As of: 3/4/2021

We have just upgraded our internet supplier (to US based) which now allows you to watch all the latest US streaming channels . We include premium channels including Netflix, Hulu, Amazon, Youtube, etc. **With a simple remote you get access to an endless supply of over 500,000+ movies and TV episodes from top free and paid channels, so you can stream almost anything including Movies, TV episodes, live sports, news, music, kids, family, fitness, and much more!**

Note: Even though we upgraded to our internet to one of the fastest available, this is Mexico, and streaming channels take a lot of “bandwidth” which means from time to time you might get a “buffering” effect which causes the playback to freeze/delay until the download data stream catches up. This seems to vary and if you have issues, try another TV location or another channel. Also remember the internet gets its signal from the satellite antennas which means during rainy or cloudy days the service may be interrupted.

DVD player is available upon request. Contact Ben

Library

There are several devices/boxes behind the wooden doors under the TV. there is the larger **Pyle Bluetooth Receiver** all house speakers are connected to. **TS6** speaker control box (each button turns speakers around the home on or off). **Speaker volume** White knob controls the volume for the front 2 speakers in that room on the front wall by the ceiling

Watching TV in the Library - Make sure source/input is set to “HDMI1”

Listening to music through your Phone/MP3 player

1. On the front of the Pyle receiver amp there are inputs for your phone or mp3 player. It is Bluetooth so connecting is easy! Make sure the mode (input) is set correctly on the Pyle amp, The connection is called BT Audio. There is also a usb in case you use a flash drive to play your music.

Listening to Streaming Music Channels

1. Basically the same steps as watching TV above except you will play the TV channel throughout the home (see **Additional Tips** for playing Music throughout the home later in this guide)

2. Turn on (as indicated above) and set the volume for the TV off or very low.
 3. Turn on the Pyle receiver/amp by selecting the power button on the remote or by pushing the power button on the left side of the receiver.
 4. Make sure the receiver/amp "input" is set "DVD/CD" To change the input push the input button just left of the large volume knob
 5. **Sound zones** There are 6 numbered buttons on the front of the **TS6 speaker control box** (The zones *SHOULD BE* as listed below, but things get rewired at times) Zone 1 is the front speakers in the library, Zone 2 is the speakers outside the library by the outside fireplace, Zone 3 is the speakers in the great room, Zone 4 is the speakers in the Master bedroom, Zone 5 is the outside covered patio ceiling speakers, Zone 6 is currently not used. All buttons are to be pushed in on the **TS6** speaker control box (each button turns speakers around the home on/off).
Please note individual **Volume Control** knobs are on the walls in various rooms/zones. The volume control for the library speakers (zone 1) is located inside the cabinet under the TV. Each knob controls the speaker volume in the immediate area/zone...remember, the speakers only work if the corresponding button on the **TS6** control box in the library is pushed in.
- Remember there are outside speakers. Be thoughtful of the neighbors and turn off the speakers outside when not needed

Master Bedroom

To watch TV in Master - Make sure the Akai TV has to be on and the input "source" is set to "AV". To change the source use the Akai remote or to manually press the source button on the TV, then the up/down arrows and the finally the volume + (right arrow)

4th Bedroom

To watch TV in the far back bedroom Make sure the TV has to be on and the input "source" is set to "HDMI1". To change the source use the TV remote or to manually press the source button on the TV, then the up/down arrows and the finally the volume + (right arrow)

****PLEASE** Check the remotes when you arrive to make sure you have all the remotes you should have. Check again when you leave. You will be charged for lost remotes or the time it takes to "find" remotes that are NOT in the remote box. You would be amazed "where" we finally find remotes and the

hours and hours we spend looking for lost remotes!