Garmin Autopilot Setup Reference Sheet

*Please Key On the motors

Changing the GPS Preferred Sources on the GHC 20

On the GHC 20. Select *Menu> Setup> Preferred Source > GPS >* Change from "Auto" to "19X"

*(If a 19X antenna is not present select a Garmin chartplotter)

Changing the Navigation Preferred Source

On the GHC 20. Select Menu> Setup> Preferred Source > Navigation

Change from "Auto" to a Garmin chartplotter.

*If "Attitude" is an option in Preferred Source, change from "Auto" and select "Reactor"

Changing the Speed Source

On the GHC 20 helm display, from the heading screen, select *Menu > Setup > System> System Information*.

Hold the center key for 5 seconds. Dealer Mode appears.

Select Back > Back

If the option for Dealer Autopilot Setup is available on the Setup screen, the procedure was successful.

Go into Dealer Autopilot Setup > Speed Source Setup select N2K tach

It will ask to verify tach, select Ok

Changing the Preferred Source(s) on Chartplotter

On the chartplotter. Select Settings> Communications> Preferred Sources

Change GPS source from "Auto" to "19x" if one is installed. If not change it to the chartplotter

Change Navigation source from "Auto" to the Garmin chartplotter.

Garmin Autopilot Setup Reference Sheet

Enabling Autopilot function on Chartplotter

If a Garmin autopilot is connected to a Garmin chartplotter the autopilot function must be enabled to be able to engage the autopilot from the chartplotter. To enable the autopilot on the chartplotter: *Home> Settings> System> Station Information> Autopilot Enable*.

*If the Autopilot Enable feature is not present check connections to the autopilot to make sure it is communicating on the NMEA 2000 network.

Enabling Dealer Autopilot Setup

On the GHC 20 helm display, from the heading screen, select *Menu > Setup > System > System Information*.

Hold the center key for 5 seconds. Dealer Mode appears. Select Back > Back

If the option for Dealer Autopilot Setup is available on the Setup screen, the
procedure was successful.

*If there is not a GHC 20 present. On the Garmin Chartplotter. Settings> My Vessel> Autopilot Installation Setup.