ITS TechDocs

Keiper 114: Directions for Use

Last Revised 8-16-23

General Directions

- 1. Press the touch screen on the podium to begin. The projector will turn on automatically.
- 2. Choose a source by pressing the **Sources** button on the screen. Then press the Source you desire.

HDMI Room PC Mersive USB-C

- 3. Control the **Volume** at the right side of the screen.
- 4. Always press the **Power** button to shutdown the projector and system when you have finished. "**Are you sure** you want to exit and shut the system down?" Press "Yes".

N.B. - Do not use Video Mute to shut down - you will burn up the projector. Always Unmute before shutdown.

To Display the Room PC

- 1. Press the **Power** button on the right rear of the computer (if necessary, to turn it on).
- 2. Press the Room PC source on the touch screen.
- 3. Log in to the computer using your F&M Net ID. When done Log Out DO NOT Shutdown the computer.

N.B. - A USB jack is located on the front of the rack. Insert your USB memory stick into the jack.

To Display a Laptop

- 1. Press the source you desire: **HDMI** or **USB-C**.
- 2. Attach the appropriate cable to your laptop or device.

To Display your Laptop Wirelessly

See the ITS TechDoc - Using Mersive's "Solstice" Application to Display Laptop Wirelessly (Touch-Panel Version)

To Use the built-in Vaddio Video-conferencing Camera and Mic

See the ITS TechDoc - "Using a Built-In Vaddio Video-Conference System"

Final Shutdown

- 1. Coil up the **HDMI** and **USB-C** cables individually, so they will not be stepped upon.
- 2. Remove any **USB memory** sticks.
- 3. Turn off the goose-neck lamp if on.
- 4. Always press the **Power** button to shutdown the projector and system when you have finished. "**Are you sure you want to exit and shut the system down?**" Press "**Yes**".

N.B. - Do Not use the Environment controls to shutdown the system - you may create problems for the next user.

For Assistance: Call the ITS Help Desk: 717-358-6789