

Chromebook Bluetooth Issues

Bluetooth Issue	
Issue	Possible Solutions
Bluetooth issues	If you run into issues while attempting to pair or use a Bluetooth device with the Chromebook, try the following steps to resolve the issue: 1. First, make sure that the Bluetooth device you are trying to pair is supported by the Chromebook. 2. Try disabling and re-enabling Bluetooth connectivity from the status area in the lower-right corner. 3. Try restarting the Chromebook. 4. If you are still encountering an issue with bluetooth, contact Building Technical Support.