

To program Nordic Hot Tubs filter duration cycles:

**1. Press and release a TEMP button, while the water temperature is flashing, press and release the JET button.**

**2. Use a TEMP button to change the filter cycle.**

**Duration Choices:**

**-MS & SE (single pump models) choices: F1-F8**

**-LS (dual pump model choices): F2, F4, F6, F8, FILC (Filter Continuously)**

Note: F1= runs the low speed pump for 1 hour twice per day. F2= 2 hour twice per day, etc.

**3. The control will time out of the programming after 8 seconds.**

Note: The newly programmed filter duration cycle will not start until the next day. (Turning the power to the hot tub off and then back on, will immediately start the new programmed filter cycle.)

Note: Well insulated hot tubs, like Nordic, will overheat if the filter cycle durations are set too long, especially during the hot summer months. The low speed pump alone, no heater, running for multiple hours will slowly overheat the spa. If this happens, temporarily remove the spa cover and lower the filter cycle duration.