## **Open STL With functionality**


(User Manual)

- 1. Install ZW3D 2022 SP or newer version from https://www.zwsoft.com/download
- 2. Download the ScanCenterToZw3dPlugin.dll plugin from the link;
- 3. Launch ZW3D 2022 SP;
- 4. In the ZW3D ribbon, select "Application Manager";
- 5. In the window that appears, in the "Plugin Applications" tab, click "Load DII";
- 6. Find the ScanCenterToZw3dPlugin.dll plugin and click "Open";
- 7. Check the box next to the plugin.


## The checkbox next to the plugin must be activated!

- 8. Click OK.
- 9. Launch ScanCenterNG 2022.1 or newer.
- 10. Open any scanproj project. in normal mode or in editor mode, import the desired meshes.
- 11. Select one or more meshes in the tree to open them in ZW3D.

12. Go to the main menu of ScanCenter NG



13. Click the Open STL With button and specify the system directory where the ZW3D.exe file is located



14. Click the Open button.

Wait! The selected 3d meshes should open in ZW3D.