
# CLEANING DJI MATRICE 300 RTK UAPS M300 ASSEMBLY & DISASSEMBLY STEP-BY-STEP GUIDE. (04/2022)

### Cleaning UAPS SL After Use -

- o Put on PPE including visor
- Place UAPS SL on test stand and run a litre of specialist herbicide cleaning solution through the UAPS SL
- Remove the nozzle and control valve by gently drawing the nozzle holder from the front of the lance \*note orientation ring on control valve





O Gently disconnect the control valve from the sprayer end of the feed tube



O Separate the control valve and the nozzle from the nozzle holder and place all the components in a bath of specialist herbicide cleaning solution




O After leaving the components it to soak for several minutes blow the control valve (in the correct orientation) and the nozzle through with canned air, repeat if necessary





o Reassemble and refit the control valve (in the correct orientation) and nozzle holder assembly, refit nozzle and check UAPS SL for good operation





- o Breakdown and box UAPS SL
- o Store equipment carefully remembering to ensure periodic free movement of air in UAPS SL box if it is to be stored for more than 1 week, in case of mould growth (silica Bags)