

Connect your Chromebook to Wi-Fi

To connect to the Internet, use a compatible Wi-Fi network.

Step 1: Turn on Wi-Fi

1. At the bottom right, select the time.
2. Select Not Connected  .
Note: If you see your Wi-Fi network name and a signal strength, your Chromebook is already connected to Wi-Fi.
3. Turn on Wi-Fi.
4. Your Chromebook will automatically look for available networks and show them to you in a list.

Step 2: Pick a network and connect

1. Select your secure Wi-Fi network .
2. Type the network password.
3. Select Connect.

Conecte su Chromebook a Wi-Fi

Para conectarse a Internet, use una red Wi-Fi compatible.

Paso 1: enciende Wi-Fi

1. En la parte inferior derecha, selecciona la hora.
2. Seleccione No conectado  .
Nota: Si ve el nombre de su red Wi-Fi y la intensidad de la señal, su Chromebook ya está conectada a Wi-Fi.
3. Enciende el wifi.
4. Su Chromebook buscará automáticamente las redes disponibles y se las mostrará en una lista.

Paso 2: Elija una red y conéctese

1. Seleccione su red Wi-Fi segura .
2. Escriba la contraseña de la red.
3. Seleccione Conectar.