



**\*\*This mount is shown for the left facing orientation, if you ordered right, it will just be inversed\*\***  
The mount orients on the wall like so:



The ship slides into the locks like this:



When installed it should pop into place:



To release the ship from the mount, press here while pulling the nose of the ship away from the wall:

