

Turn **ON** the scooter

1.- Double click on **M**, P1 appears, them;



2.- Click on **+** until P1⁴ appears



3.- Click on **M** to P5⁰



4.- Click on **M** 4 times to set **0000**, them appears **P0¹ ON**;



5.- Press **M**, them **+** to change to **P0² APSO**;



6.- Press **M** to AP5; them Press **(+ -)** to set the first digit of your password;



7.- Press (+ -) to set the second digit of your password;



8.- Press (+ -) to set the third digit of your password;



9.- Press (+ -) to set the fourth digit of your password;



11.- Press **M** to return to the main screen;



12.- Turn **off** and **on** to verify the password set up.